



SPBW1035

Portable Waterproof (IPX6) Bluetooth Speaker System with Speakerphone



INSTRUCTION MANUAL

Introduction:


Thank you for choosing this product as your source for entertainment! You can use this item with iPads, iPhones, iPods, and many types of smartphones to stream music, and enjoy handsfree calling. In order to get the best results when using the device, please read this manual first before using.

Important Waterproof / Safety Information:

IMPORTANT: DO NOT submerge the speaker in water! This unit is not intended to function properly after being under water. This unit is rated IPX6, which means the speaker can be heavily splashed with water or left in the rain (but not submerged in water) for approximately a limited time. If the unit gets wet, it is recommended that you dry the speaker completely before using it again.

PLEASE NOTE: The speaker is NOT water-resistant when the silicone cover is open. Please make sure that cover is closed completely and secure before using in a wet environment.

Description:



1. ON/OFF button
2. Play / Pause / Phone
3. MIC
4. Previous / Volume -
5. Next / Volume +
6. Blue LED (Bluetooth)
7. Red LED (Charging)
8. Green LED (AUX)
9. Micro USB Charging Port
10. AUX in Port

Included:

1. Speaker
2. USB Micro Charging Cable
3. 3.5 mm Audio Cable
4. User Manual

Specifications:

Supported Profiles: A2DP, HFP, AVRCP
Bluetooth Version/Range: v2.1, 33ft (10m)
Dimensions: 180 mm x 65 mm
Battery: Li-Ion 3.7V, 1000 mAh
Charging: 5V @ 500 mA

Operation:

POWERING ON

Press and Hold "ON/OFF" button 2 seconds to power ON, the Blue LED will start to flash.

If an Aux (3.5 mm) cable is connected to the unit, the Blue LED will turn off, and the Green LED will stay illuminated, notifying you, the unit is in Aux-In mode.

POWERING OFF

Press and Hold "ON/OFF" button 2 seconds to power OFF

Bluetooth Mode:

PAIRING

The unit will automatically go into "Pairing Mode" when it is powered ON.

Go into your Bluetooth device settings menu and look for "SPBW1035".

After the unit has paired and connected, it will re-connect automatically when the unit is powered on and the device is in range.

NOTE: Bluetooth Timeout - 10 minutes

Begin Streaming Music:

Press "🎵" to start playing music

Press and Hold "⏸" 2 seconds to play the next track

Press and Hold "⏮" 2 seconds to play previous track

Press either "⏸" or "⏮" for volume control

Making and Receiving Phone Calls:

When the unit is connected and paired to your device, it allows you to make or receive phone calls with its built-in microphone.

Press "🎵" to accept a call.

To end a call press "🎵".

To place a call, simply dial the number or select a contact.

To reject a call, press and hold "🎵" for 2 seconds.

Aux-In Mode:

Plug in the supplied 3.5 mm cable into the unit. The other end is connected to your device. The Green LED will only illuminate when in "Aux-In" mode.

PLEASE NOTE: Music and volume can be controlled by your device.

Charging:

Attach the USB cable to the unit, and plug into any USB charger.

If the unit is completely discharged, it will take approximately 4 hours to fully charge.

The Red LED will illuminate during charging. When it has completed, the Red LED will turn off.

NOTE: There will be a beeping sound when the battery is low and needs to be recharged.

LED Status:

Blue LED flashing & Green LED solid	Bluetooth Mode
Green LED on solid	Aux Mode, Charging Completed
Red LED	Charging

Troubleshooting:

Unit doesn't connect to device	Speaker needs to be connected / re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Unit will not power on	Speaker needs to be charged
Unit doesn't control track(s)/volume	Speaker needs to be in Bluetooth mode for full control
Unit distorts at high volume	The devices' volume needs to be lowered

Axess Products Corporation

6639 Valjean Ave Van Nuys CA 91406

Tel: 818-785-4000 • Fax: 818-785-5081 • info@axessusa.com

Questions? Comments? Contact us at support@axessusa.com

© 2014 Axess Products Corporation. All rights reserved.